

Surface Mount Template

Use this template to mount the surge protector on any surface with screws



Use two #6 sheet metal screws (not included).
Screw heads should protrude about 1/8".

